



NOTES:

1. SADDLES SHOULD BE LOCATED IN VALLEYS BETWEEN ROOF DRAINS, AND CRICKETS SHOULD BE LOCATED ON THE HIGH SIDE OF CURBS.
2. LOCATE ROOF DRAINS AT POINTS OF MAXIMUM DECK DEFLECTION/LOW AREAS FOR DRAINAGE.
3. SADDLE INSULATION MAY BE SANDWICHED BETWEEN LAYERS OF FLAT STOCK INSULATION

RECOMMENDED MAXIMUM L:W RATIOS FOR SADDLES AND CRICKETS

ROOF SLOPE	SADDLE MATERIAL SLOPE	L:W RATIO
1/8	1/4	3:1
1/4	1/2	3:1
1/2	1/2	4:1

This detail is furnished "as is" and "as available" and for information only and as a guide for use in conjunction with U.S. Ply products with applicable construction conditions. All dimensions shown are sheet specific; do not scale off of drawing. All details must be checked by the user's designer, architect or engineer to ensure that design is adequate for intended use. Any alterations made to this detail become the design of the user and shall neither be assumed nor construed as U.S. Ply's design. U.S. Ply will not be liable for damages of any kind arising from the use of this website, and/or details, including direct, indirect, incidental, consequential and punitive damages.



U.S. PLY, INC.

Pioneered with performance in mind... Engineered to stand the test of time.

TITLE:

CRICKET AND SADDLE DETAIL

DATE:
05-14-2004

REVISIONS:
01-31-2011

SCALE:
N.T.S.

CS-1